

Application Instructions to install carbon fiber door cups.

Tools & Materials Needed

Pre-cut Carbon fiber door Cups

Spray bottle with 50/50 Isopropyl alcohol and water

Small flexible squeegee or kitchen spatula

Microfiber cloth

1. Wash the door handle area with soap and water to remove any dirt and debris.
 2. Thoroughly clean the door handle area with the isopropyl alcohol/water mixture to remove all waxes, minerals and oils.
 3. Dry the area with a clean microfiber cloth.
 4. Peel the backing off the back of the carbon fiber protector.
 5. Carefully align the carbon fiber door cup under the door handle, starting with the concave side on the left and firmly press in place going from left to right. Using a kitchen spatula or flexible squeegee will help push the air out from under the door cup and secure the product in place.
- DO NOT use any liquid or soapy solutions to apply this product.

For better adhesion and forming, use a heat gun on low heat or a blow dryer after application. Avoid washing or getting the area wet for 24-48 hours.

Instrucciones de aplicación para instalar los marcos de fibra de carbono.

Herramientas y materiales necesarios:

Marcos de fibra de carbono precortados

Botella rociadora con alcohol isopropílico y agua (50/50)

Espátula de cocina flexible pequeña

Paño de microfibra

1. Lave la zona de la manija de la puerta con agua y jabón para eliminar la suciedad y los residuos.
2. Limpie a fondo la zona de la manija con la mezcla de alcohol isopropílico y agua para eliminar ceras, minerales y aceites.
3. Seque la zona con un paño de microfibra limpio.
4. Retire el protector de fibra de carbono.
5. Alinee cuidadosamente el marco de fibra de carbono debajo de la manija, comenzando por el lado cóncavo de la izquierda y presione firmemente de izquierda a derecha. Usar una espátula o una espátula de cocina flexible ayudará a expulsar el aire de debajo del marco y a fijar el producto en su lugar.

NO utilice soluciones líquidas ni jabonosas para aplicar este producto.

Para una mejor adhesión y formación, utilice una pistola de calor a baja temperatura o un secador después de la aplicación. Evite lavar o mojar la zona durante 24 a 48 horas.