Application Instructions

Tools & Materials Needed:

Pre-cut PPF door cup kits
Spray bottle with slip solution (distilled water + a few drops of baby shampoo or dish soap)
Spray bottle with tack solution (distilled water + 70% isopropyl alcohol; approx. 25% alcohol)
Squeegee (small and soft edge)
Microfiber cloths

1. Wash the area thoroughly with soap and water. Dry with a clean microfiber cloth.
   Use isopropyl alcohol to remove any wax, grease, or residue.
2. Generously spray slip solution on your fingers (to prevent fingerprints). Spray the adhesive side of the PPF and the door cup area with slip solution.
3. Peel the film from the backing. Apply film to the wet door cup area.
   Slide the film into the correct position using your fingers.
4. Spray tack solution underneath the film's edges if they aren't sticking. Gently lift the edge, spray tack solution, and re-smooth.
5. Use the squeegee to push out water and air from the center outward.
   Re-apply slip solution to the top of the film if needed to reduce friction.
   Avoid washing or getting the area wet for 24–48 hours.

Instrucciones de aplicación

Herramientas y materiales necesarios:

Kits de marcos de puerta PPF precortados
Botella rociadora con solución deslizante (agua destilada + unas gotas de champú para bebés o jabón lavavajillas)
Botella rociadora con solución adhesiva (agua destilada + alcohol isopropílico al 70 %; aprox. 25 % de alcohol)
Espátula (pequeña y suave)
Paños de microfibra

1. Lave bien la zona con agua y jabón. Seque con un paño de microfibra limpio.
Use alcohol isopropílico para eliminar cualquier cera, grasa o residuo.
2. Rocíe generosamente la solución deslizante en los dedos (para evitar huellas dactilares).
   Rocíe la parte adhesiva del PPF y la zona del marco de la puerta con la solución deslizante.
3. Retire la película del soporte. Aplique la película sobre la zona húmeda del marco de la puerta.
   Deslice la película en la posición correcta con los dedos.
4. Rocíe la solución adhesiva debajo de los bordes de la película si no se adhieren.
   Levante suavemente el borde, rocíe la solución de adherencia y vuelva a alisarlo.
5. Use la escobilla de goma para expulsar el agua y el aire desde el centro hacia afuera.
   Reaplica la solución de adherencia en la parte superior de la película si es necesario para reducir la fricción.
   Evite lavar o mojar la zona durante 24 a 48 horas.

I9029